Date	Unit Number	Appliance	Fault detail
24/04/2015	HPG145	WELL217	Rivets broken/missing from Stand pipe bracket and key and bar bracket at rear of vehicle.
10/06/2015	HPG145	WELL217	Hinge come away on cab storage box
11/06/2015	HPG145	WELL217	Suction hose storage box flexing and coming apart, spring missing in slide out tray, LED locker strip light failing.
11/06/2015	HPG145	WELL217	Cab door hinge coming away from door.
30/06/2015	HPG145	WELL217	Adjust rear door
5/08/2015	HPG145	WELL217	Ladder hold down handle not fully welded, causing cracking of bracket.
			Near side A locker light not working in bottom section. Nearside C locker pull out tray spring on latch not returning. Foam tank
6/08/2015	HPG145	WELL217	rubbing on chassis bolts.
2/10/2015	HPG145	WELL217	Reversing Buzzer died
19/10/2015	HPG145	WELL217	BA board wiring
20/10/2015	HPG145	WELL217	Adjust door lock, tight grab handle screws, replace seat tape, repair locker shelf lock under warranty
23/10/2015	HPG145	WELL217	Near side Hose reel not rewinding, motor needs replacing as well as circuit breaker
10/11/2015	HPG145	WELL217	Locker jammed
14/01/2016	HPG145	WELL217	Rear inside door handle not working
14/01/2016	HPG145	WELL217	Rear inside door handle not working
21/01/2016	HPG145	WELL217	Foam refill pump not working
22/01/2016	HPG145	WELL217	Oil weep from H100 pump bearing cap.
26/01/2016	HPG145	WELL217	Replace damaged light
31/01/2016	HPG145	WELL217	Door repairs
16/02/2016	HPG145	WELL217	Door repairs
23/02/2016	HPG145	WELL217	Internal cab door handle broken linkage.
10/03/2016	HPG145	WELL217	Door repairs
10/03/2016	HPG145	WELL217	Rear internal door handles over open and dislodge mechanism locking door
			Left Hand Rear door - door skin spot welds broken and door skin is coming away from frame, also noted cracks in door and hinge is
10/03/2016	HPG145	WELL217	stiff and wearing as metal on metal contact.
6/05/2016	HPG145	WELL217	Door repairs
6/05/2016	HPG145	WELL217	Door repairs
6/05/2016	HPG145	WELL217	Door repairs
13/06/2016	HPG145	WELL217	Replace foam refill pump
12/07/2016	HPG145	WELL217	Catches on Near side C locker tray have failed and do not lock the tray in the stowed position.
25/07/2016	HPG145	WELL217	Dash Area where officers helmet mount is has come adrift
29/07/2016	HPG145	WELL217	Replace slides
2/08/2016	HPG145	WELL217	Primer Motor doesn't work.
11/10/2016	HPG145	WELL217	Door repairs
19/10/2016	HPG145	WELL217	Near side rear door skin is separating away from the door skin creating a lot of flex and door dropping.
		▼	

Date	Unit Number	Appliance	Fault detail
			The window winder for the Passenger side rear position has stripped the teeth on the winding handle and makes it difficult to wind
7/11/201	6 HPG145	WELL217	the window down.
8/11/201	6 HPG145	WELL217	Replace bulb, repair primer, adjust bushes
21/11/201	6 HPG145	WELL217	Refit tank lid seal
15/12/201	6 HPG145	WELL217	Door repairs
19/12/201	6 HPG145	WELL217	Seat belt and speedo sensor faults
26/01/201	7 HPG145	WELL217	LH Rear door dropped, RH rear door pulling away from skin and door, doesn't always open from the inside.
31/01/201	7 HPG145	WELL217	Door repair
22/02/201	7 HPG145	WELL217	Flat batteries
22/02/201	7 HPG145	WELL217	Repair branch holder
28/02/201	7 HPG145	WELL217	Resecure air tank drain cord bracket
2/03/201	7 HPG145	WELL217	Door repair
3/03/201	7 HPG145	WELL217	Rear beacon not working.
16/03/201	7 HPG145	WELL217	Replace bulb, batteries, door switch cover. Clean primers.
23/03/201	7 HPG145	WELL217	BA board charging fault
23/03/201		WELL217	Door repairs
22/05/201	7 HPG145	WELL217	Investigate brake warning light
21/06/201	7 HPG145	WELL217	BA board charging fault
28/06/201		WELL217	Replace damaged light
14/08/201		WELL217	Beacon off side rear no light
17/08/201		WELL217	Repair seat belt
30/08/201		WELL217	Door repair
29/04/201		AUCK207	Controls for near-side panel lights, scene lights, mast light, hose reel rewind not working.
19/06/201		AUCK207	Inlet valve repair
	5 HWD384	AUCK207	Air horn fails while responding.
14/07/201		AUCK207	Replace helmet bracket
	5 HWD384	AUCK207	Ladder crashing into gantry cross beam and top guides
17/08/201		AUCK207	Secure grab handle and clearn sight tube
	5 HWD384	AUCK207	Replace locker latches
19/10/201		AUCK207	The front grab handle on the rear door of the drivers side pulled out of the roof.
	5 HWD384	AUCK207	LH rear door handles both inside and out not working
13/11/201		AUCK207	Door handle issue
31/12/201	5 HWD384	AUCK207	Door handle issue
		ON	

12/02/2016 HWD384

AUCK207

Major problems getting the class 1 update to take. Pump throttle message not getting to engine after class 1 program update.

DateUnit NumberApplianceFault detail12/02/2016HWD384AUCK207Ik door has popped open twice while driving12/02/2016HWD384AUCK207Clean foam injector and valves, replace light19/02/2016HWD384AUCK207Clean foam injector and valves, replace light19/02/2016HWD384AUCK207Side emergency flashner wire has dropped and is damaged by wheel18/03/2016HWD384AUCK207Side emergency flashner wire has dropped and is damaged by wheel18/03/2016HWD384AUCK207Rivets failing on body18/04/2016HWD384AUCK207Replace indicator bulbs12/07/2016HWD384AUCK207Replace indicator bulbs12/07/2016HWD384AUCK207Replace indicator bulbs12/07/2016HWD384AUCK207Replace indicator bulbs12/07/2016HWD384AUCK207Replace indicator bulbs12/07/2016HWD384AUCK207Replace banged 230V socket6/09/2016HWD384AUCK207Replace banged 230V socket6/09/2016HWD384AUCK207Replace batteries and repaired door switch13/09/2016HWD384AUCK207Replace batteries and repaired door switch13/09/2016HWD384AUCK207Replace batteries and repaired door switch13/09/2016HWD384AUCK207Replace indicated and pupp outlet.3/09/2015HY0165GREY261Pounp engagement intermittent.19/06/2015HY0165GREY261Pounp engagement intermittent. <th>Data Ust Number</th> <th>Andless</th> <th></th>	Data Ust Number	Andless	
12/02/2016HWD384AUCK207LR door has popped open twice while driving19/02/2016HWD384AUCK207Clean foam injector and valves, replace light19/02/2016HWD384AUCK207Side emergency flashing light not working, loom hanging down and damaged by tyre.19/02/2016HWD384AUCK207Side emergency flashing light not working, loom hanging down and damaged by tyre.19/03/2016HWD384AUCK207Rivets failing on body18/04/2016HWD384AUCK207Robace emergency flashing light not working, loom hanging down and damaged by tyre.12/07/2016HWD384AUCK207Roplace indicator bulbs12/07/2016HWD384AUCK207Replace indicator bulbs12/07/2016HWD384AUCK207Replace damaged 230V socket26/07/2016HWD384AUCK207Replace halbe ansor and beacon issue1/08/2016HWD384AUCK207Replace dateries and repaired door switch1/08/2016HWD384AUCK207Replace dateries and repaired door switch1/08/2016HWD384AUCK207Dorawer slides and repaired door switch1/08/2016HWD384AUCK207Drawer slides and repaired door switch1/08/2015HYQ165GREY261Pump engagment intermittent.1/08/2015HYQ165GREY261Air horn fails while responding.2/07/2015HYQ165GREY261Air horn shils mile responding.2/07/2015HYQ165GREY261Fix locker door3/07/2015HYQ165GREY261Fix locker door3/0			Fault detail
19/02/2016 HWD384AUCK207Clean foam injector and valves, replace light19/02/2016 HWD384AUCK207Door handle issue19/02/2016 HWD384AUCK207Side emergency flashing light not working, loom hanging down and damaged by tyre.29/03/2016 HWD384AUCK207Rivets failing on body18/04/2016 HWD384AUCK207Replace indicator bulbs29/06/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace indicator bulbs29/06/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace hubo29/06/2016 HWD384AUCK207Replace hubo29/06/2016 HWD384AUCK207Replace hubo29/07/2016 HWD384AUCK207Replace bubo29/07/2016 HWD384AUCK207Replace batteries and repaired door switch1/08/2016 HWD384AUCK207Replace batteries and repaired door switch3/07/2017 HWD384AUCK207Replace datereis and repaired door switch3/07/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Pump engagment intermittent.3/07/2015 HYQ165GREY261Abs hight come on intermittently.23/07/2015 HYQ165GREY261Abs hight come on intermittently.23/07/2015 HYQ165GREY261Abs hight come on intermittently.23/07/2015 HYQ165GREY261Esp putting truck into limp mode24/08/2015 HYQ165GREY261Fix locker door <tr< td=""><td>1 1</td><td></td><td></td></tr<>	1 1		
19/02/2016 HWD384AUCk207Door handle issue19/02/2016 HWD384AUCk207Side emergency flasher wire has dropped and is damaged by wheel18/03/2016 HWD384AUCk207Rivets failing on body29/03/2016 HWD384AUCk207Rivets failing on body18/04/2016 HWD384AUCk207Replace indicator bubbs29/06/2016 HWD384AUCk207Replace indicator bubbs12/07/2016 HWD384AUCk207Replace indicator bubbs12/07/2016 HWD384AUCk207Replace damaged 230V socket26/07/2016 HWD384AUCk207Replace damaged 230V socket26/07/2016 HWD384AUCk207Replace damaged 230V socket10/8/2016 HWD384AUCk207Replace damaged 230V socket26/07/2016 HWD384AUCk207Replace damaged by virce10/8/2016 HWD384AUCk207Replace damaged isour isoue11/08/2016 HWD384AUCk207Replaced batteries and repaired door switch31/07/2017 HWD384AUCk207Replaced batteries and repaired door switch31/07/2017 HWD384AUCk207Drawer sildes and repair TPM19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261ADS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking3/09/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/09/2015 HYQ165GREY261Foam refile place boken2/12/2016 HYQ165GREY261Foam refile place boken2/12/2016 HYQ165GREY261Foam refile place bok			
19/02/2016 HWD384AUCK207Side emergency flashing light not working, loom hanging down and damaged by tyre.18/03/2016 HWD384AUCK207Rivets failing on body18/04/2016 HWD384AUCK207Not specified29/03/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace indicator bulb12/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace damaged 230V socket30/09/2016 HWD384AUCK207Replace damaged 200V socket30/09/2016 HWD384AUCK207Replace damaged 200V socket31/07/2017 HWD384AUCK207Replace date on paint of the paint PM13/09/2016 HWD384AUCK207Replaced batteries and repaired door switch31/07/2017 HWD384AUCK207Replaced batteries and repaired door switch31/07/2015 HYQ165GREY261Poump engagment intermittent.19/06/2015 HYQ165GREY261Poump engagmend intermittent.3/07/2015 HYQ165GREY261ABS light come on intermittentily23/07/2015 HYQ165GREY261ABS light come on intermittentily23/07/2015 HYQ165GREY261ABS light come on intermittentily23/07/2015 HYQ165GREY261HSP putting truck into limp mode24/08/2015 HYQ165GREY261Fix locker door3/09/2015 HYQ165GREY261 </td <td></td> <td></td> <td></td>			
18/03/2016 HWD384AUCK207Side emergency flashing light not working, loom hanging down and damaged by tyre29/03/2016 HWD384AUCK207Not specified18/04/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace hubo29/07/2016 HWD384AUCK207Replace hubo29/07/2016 HWD384AUCK207Reel ocker jammed - unable to open6/09/2016 HWD384AUCK207Reel ocker jammed - unable to open6/09/2016 HWD384AUCK207Replace datteries and repaired door switch31/07/2017 HWD384AUCK207Replace datteries and repaired door switch31/07/2015 HYD165GREY261Pump engagment intermittent.19/06/2015 HYD165GREY261Pump engagment intermittent.3/07/2015 HYD165GREY261ASI inf norn fails while responding.23/07/2015 HYD165GREY261ASI inf norn fails while responding.23/07/2015 HYD165GREY261ASI inf norn fails while responding.23/07/2015 HYD165GREY261Foom reful pump cracked at pump outlet.3/09/2015 HYD165GREY261Asi inf norn fails while responding.23/07/2015 HYD165GREY261Replace door3/09/2015 HYD165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYD165GREY261Foom handle release cable broken22/1			
29/03/2016 HWD384AUCK207Rivets failing on body18/04/2016 HWD384AUCK207Not specified29/06/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace switch covers, bulb, check fault light12/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace damaged 230V socket1/08/2016 HWD384AUCK207Replace bulbo29/07/2016 HWD384AUCK207Rear locker jammed - unable to open1/08/2016 HWD384AUCK207Rear locker jammed - unable to open1/08/2016 HWD384AUCK207Replace batteries and repaired door switch3/09/2016 HWD384AUCK207Replace batteries and repaired door switch3/09/2015 HWD165GREY261Pump engagment intermittent.19/06/2015 HV0165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HV0165GREY261Air form fails while responding.23/07/2015 HV0165GREY261ABS light come on intermittently23/07/2015 HV0165GREY261ABS light come on intermittently23/07/2015 HV0165GREY261Nearside B locker roller mechanism has detached and disappeared.3/02/2015 HV0165GREY261Nearside B locker roller mechanism has detached and disappeared.3/02/2015 HV0165GREY261Foult come and refit 4 delivery outlets, due to leaking3/02/2015 HV0165GREY261Foult code and foam issue3/03/2015 HV0165GREY261Foult code and			
18/04/2016 HWD384AUCK207Not specified29/06/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace switch covers, bulb, check fault light12/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace hubo29/07/2016 HWD384AUCK207Replace hubo1/08/2016 HWD384AUCK207Rear locker jammed - unable to open6/09/2016 HWD384AUCK207Check 230V circuit13/09/2016 HWD384AUCK207Replaced buteries and repaired door switch13/09/2016 HWD384AUCK207Replaced buteries and repaired door switch13/09/2016 HWD384AUCK207Drawer slides and repair TPM13/09/2015 HWD165GREY261Pump engagment intermittent.19/06/2015 HVD165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HVD165GREY261Air horn fails while responding.23/07/2015 HVD165GREY261Air horn fails while responding.23/07/2015 HVD165GREY261ESP putting truck into limp mode24/08/2015 HVD165GREY261ESP putting truck into limp mode24/08/2015 HVD165GREY261Fix locker door3/12/2015 HVD165GREY261Foat code and foam issue3/09/2015 HVD165GREY261Horn switch22/12/2015 HVD165GREY261Foat code and foam issue3/09/2016 HVD165GREY261Foat code and foam issue3/09/2016 HVD165GREY261Replace door anil, suspect low water alarm is tripping but the MAN one isn't </td <td></td> <td></td> <td></td>			
29/06/2016 HWD384AUCK207Replace indicator bulbs12/07/2016 HWD384AUCK207Replace damaged 230V socket12/07/2016 HWD384AUCK207Replace damaged 230V socket25/07/2016 HWD384AUCK207Replace hubo29/07/2016 HWD384AUCK207Lambda sensor and beacon issue1/08/2016 HWD384AUCK207Reerl ocker jammed - unable to open6/09/2016 HWD384AUCK207Reerl ocker jammed - unable to open1/08/2016 HWD384AUCK207Reerl ocker jammed - unable to open13/09/2016 HWD384AUCK207Replace datteries and repaired door switch13/09/2016 HWD384AUCK207Replaced batteries and repaired door switch13/09/2016 HWD384AUCK207Replaced batteries and repaired door switch13/09/2015 HVQ165GREY261Poamer sfilds and repair TPM18/06/2015 HVQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HVQ165GREY261Air horn fails while responding.23/07/2015 HVQ165GREY261Offside Delivery valve leaking4/08/2015 HVQ165GREY261ESP putting truck into limp mode24/08/2015 HVQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HVQ165GREY261Lf door handle release cable broken22/12/2015 HVQ165GREY261Foan witch23/07/2015 HVQ165GREY261Foan witch23/02/2016 HVQ165GREY261Foan witch25/01/2016 HVQ165GREY261Foan do am issue31/03/2015 HVQ165GREY261Foan do am issu			
12/07/2016 HWD384AUCK207Replace switch covers, bulb, check fault light12/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Lambda sensor and beacon issue1/08/2016 HWD384AUCK207Lambda sensor and beacon issue1/08/2016 HWD384AUCK207Reer locker jammed - unable to open6/09/2016 HWD384AUCK207Check 230V circuit13/09/2016 HWD384AUCK207Replace dbatteries and repaired door switch13/09/2016 HWD384AUCK207Drawer slides and repair TPM18/06/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261Merside Blocker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261Foam switch22/12/2015 HYQ165GREY261Foam switch23/07/2015 HYQ165GREY261Foam switch3/09/2015 HYQ165GREY261Foa made release cable broken2/12/2015 HYQ165GREY261Foa made release cable broken2/12/2015 HYQ165GREY261Foa mode and relit 4 delivery outlets, due to leaking3/09/2016 HYQ165GREY261Kyoor sounding when on hill, suspect low water alarm is tripping			
12/07/2016 HWD384AUCK207Replace damaged 230V socket26/07/2016 HWD384AUCK207Replace hubo29/07/2016 HWD384AUCK207Lambda sensor and beacon issue1/08/2016 HWD384AUCK207Check 230V circuit13/09/2016 HWD384AUCK207Replaced batteries and repaired door switch31/07/2017 HWD384AUCK207Replaced batteries and repaired door switch31/07/2017 HWD384AUCK207Drawer sildes and repair TPM18/06/2015 HYQ165GREY261Pomp engagment intermittent.19/06/2015 HYQ165GREY261Pom refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/09/2015 HYQ165GREY261LF door handle release cable broken3/09/2015 HYQ165GREY261LF door handle release cable broken3/09/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Fault code and foam issue3/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking3/06/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking3/06/2016 HYQ165GREY261All FFR locker door rails loose against bodywork3/108/2016 HYQ165GREY261All FFR locker door rails loose against bodywork3/10/2016 HYQ165GREY261Re			
26/07/2016 HWD384AUCK207Replace hubo29/07/2016 HWD384AUCK207Lambda sensor and beacon issue1/08/2016 HWD384AUCK207Rear locker jammed - unable to open6/09/2016 HWD384AUCK207Check 230V circuit13/09/2016 HWD384AUCK207Replaced batteries and repaired door switch31/07/2017 HWD384AUCK207Drawer slides and repair TPM18/06/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261Fix locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261Computer s/w update2/00/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking3/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking3/03/2016 HYQ165GREY261All FFR locker door rails loose against bodywork3/108/2016 HYQ165GREY261All FFR locker door rails loose against bodywork3/108/2016 HYQ165GREY261All FFR locker door			
29/07/2016 HWD384AUCK207Lambda sensor and beacon issue1/08/2016 HWD384AUCK207Rear locker jammed - unable to open6/09/2016 HWD384AUCK207Check 230V circuit13/09/2016 HWD384AUCK207Replaced batteries and repaired door switch13/07/2017 HWD384AUCK207Drawer slides and repair TPM18/06/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261Difside Delivery valve leaking4/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/07/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking3/03/2016 HYQ165GREY261All FFR locker door rails lose against bodywork31/03/2016 HYQ165GREY261All FFR locker door rails lose against bodywork31/03/2016 HYQ165GREY261Fornove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261 </td <td></td> <td></td> <td></td>			
1/08/2016 HWD384AUCK207Rear locker jammed - unable to open6/09/2016 HWD384AUCK207Check 230V circuit13/09/2016 HWD384AUCK207Replaced batteries and repaired door switch31/07/2017 HWD384AUCK207Drawer slides and repair TPM18/06/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Foam refil pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittentiv23/07/2015 HYQ165GREY261ABS light come on intermittentiv23/07/2015 HYQ165GREY261Diffside Delivery valve leaking4/08/2015 HYQ165GREY261FSP putting truck into limm mode24/08/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261Fix locker door2/12/2015 HYQ165GREY261Fix locker door2/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking31/03/2016 HYQ165GREY261All FFR locker door rails loose against bodywork			
6/09/2016 HWD384AUCK207Check 230V circuit13/09/2016 HWD384AUCK207Replaced batteries and repair TPM31/07/2017 HWD384AUCK207Drawer slides and repair TPM18/06/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261LF door handle release cable broken3/1/2/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kyos sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261Replace bulb and locker lights31/08/2016 HYQ165GREY261HP gauge line blocked			
13/09/2016 HWD384AUCK207Replaced batteries and repaired door switch31/07/2017 HWD384AUCK207Drawer slides and repair TPM18/06/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261LF door handle release cable broken3/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261Fault code and foam issue3/09/2016 HYQ165GREY261Fault code and foam issue3/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking3/02/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
31/07/2017 HWD384AUCK207Drawer slides and repair TPM18/06/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261Drawride B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261LF door handle release cable broken2/12/2015 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Four switch29/02/2016 HYQ165GREY261Four on terfit 4 delivery outlets, due to leaking300/6/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
18/06/2015 HYQ165GREY261Pump engagment intermittent.19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261Diffside Delivery valve leaking4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
19/06/2015 HYQ165GREY261Foam refill pump cracked at pump outlet.3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Computer s/w update25/01/2016 HYQ165GREY261Foault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261HP gauge line blocked			
3/07/2015 HYQ165GREY261Air horn fails while responding.23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Horn switch25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
23/07/2015 HYQ165GREY261ABS light come on intermittently23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Horn switch25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261HP gauge line blocked			
23/07/2015 HYQ165GREY261Offside Delivery valve leaking4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Horn switch25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
4/08/2015 HYQ165GREY261ESP putting truck into limp mode24/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Horn switch25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261Replace bulb and locker lights31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
24/08/2015 HYQ165GREY261Nearside B locker roller mechanism has detached and disappeared.3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Horn switch25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
3/09/2015 HYQ165GREY261Fix locker door3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Horn switch25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
3/12/2015 HYQ165GREY261LF door handle release cable broken22/12/2015 HYQ165GREY261Horn switch25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
22/12/2015 HYQ165GREY261Horn switch25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
25/01/2016 HYQ165GREY261Computer s/w update29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
29/02/2016 HYQ165GREY261Fault code and foam issue31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
31/03/2016 HYQ165GREY261Remove and refit 4 delivery outlets, due to leaking30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
30/06/2016 HYQ165GREY261Kysor sounding when on hill, suspect low water alarm is tripping but the MAN one isn't11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
11/07/2016 HYQ165GREY261All FFR locker door rails loose against bodywork31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
31/08/2016 HYQ165GREY261Replace bulb and locker lights18/10/2016 HYQ165GREY261HP gauge line blocked			
18/10/2016 HYQ165 GREY261 HP gauge line blocked			
30/11/2016 HYQ165 GREY261 Headlight bulb and clear guage lines			
	30/11/2016 HYQ165	GREY261	Headlight bulb and clear guage lines

			Fault detail Puncture repair Replace sliders Exhaust tube, clean sight glass Unspecified Repair drawer, TPM and replace batteries Repair locker handle and wheel Foam refill pump leaking Air horn fails while responding.
Date	Unit Number	Appliance	Fault detail
12/12/2016		GREY261	Puncture repair
24/02/2017		GREY261	Replace sliders
20/04/2017		GREY261	Exhaust tube, clean sight glass
21/04/2017		GREY261	Unspecified
18/08/2017		GREY261	Repair drawer, TPM and replace batteries
18/08/2017		GREY261	Repair locker handle and wheel
19/06/2015		BALM611	Foam refill pump leaking
3/07/2015		BALM611	
23/07/2015	JAA112	BALM611	Reprogramme R/T
			RR door handle not returning. MAN chassis horn not workin. Sluggish power issue, noticeable when slowing then acceleratin. Both
23/07/2015	JAA112	BALM611	rear interior door handles failed.
28/09/2015	JAA112	BALM611	Repair mast light proximity switch, locker shelf
26/01/2016	JAA112	BALM611	Body computer update
2/02/2016	JAA112	BALM611	Hubometer failed
12/02/2016	JAA112	BALM611	Number's 1, 2, 3 and 4 delivery instantaneous couplings have come lose and leaking water under pressure.
19/02/2016	JAA112	BALM611	Headlight bulb
8/04/2016	JAA112	BALM611	Miscellaneous repairs
13/04/2016	JAA112	BALM611	Hose reel gauge feed line blocked causing no reading at gauge
6/05/2016	JAA112	BALM611	Blocked guage hose
13/06/2016	JAA112	BALM611	Body computer update
			Kysor alarm sounding. It started intermittently when on an incline / decline but has since progressed to operating continually when
4/07/2016	JAA112	BALM611	driving on level surfaces. Occasionally the low coolant warning light would come on the dash.
28/07/2016	JAA112	BALM611	Cooling system losing water.
31/08/2016	JAA112	BALM611	Replace master switch
6/09/2016	JAA112	BALM611	Door cable
17/10/2016	JAA112	BALM611	Foam level sensor and misc
18/10/2016	JAA112	BALM611	Hagley airhorn failed
8/11/2016	JAA112	BALM611	Hose reel jam
30/11/2016	JAA112	BALM611	Puncture repair
7/12/2016	JAA112	BALM611	Hose reel brake
7/12/2016	JAA112	BALM611	Hose reel seized
31/01/2017	JAA112	BALM611	Replace batteries
20/04/2017	JAA112	BALM611	Window switch covers, reset lights
18/08/2017	JAA112	BALM611	Repair drawer and repair TPM
18/08/2017	JAA112	BALM611	Replace battery
		•	

Date	Unit Number	Appliance	Fault detail
Date 10/06/2015		THOR231	Mast Up light staying on even with light masts down.
11/06/2015		THOR231 THOR231	Off side rear door locking system not working with the central locking
2/09/2015		THOR231 THOR231	Head rests on BA Seats coming loose
2/09/2015		THOR231 THOR231	Near side C locker bottom tray locks not releasing making tray very hard to slide in.
2/11/2015			Off side Rear cab door window tracking outside of the window seal when winding up window.
9/11/2015		THOR231 THOR231	Off side rear cab grab handle on C pillar to close to BA release arm.
7/01/2016		THOR231	Anti-Slip coating coming off roof area around monitor
13/01/2016		THOR231	Anti-Slip coating coming off roof area around monitor
31/01/2016		THOR231	Relief valve fault
17/03/2016		THOR231	Investigate warning light
5/04/2016		THOR231	Puncture repair
13/05/2016		THOR231	Panel damage and not holding prime
30/06/2016		THOR231	The yellow step plate on the lowest door step (both sides) is in contact with the bottom of the door.
11/10/2016		THOR231	Replace monitor riser switch
25/10/2016		THOR231	Monitor riser
8/11/2016		THOR231	Indicator
3/08/2017		THOR231	Minor repairs
28/08/2017		THOR231	Central locking fault
23/07/2015		PARN251	Nearside mast light tilt not working. Offside hose reel rewind not working. Water corrosion in electrical cabinet
24/07/2015		PARN251	the monitor unhoused light is staying illuminated when the monitor is housed.
4/08/2015	5 JCT115	PARN251	10.5 ladder gantry has a 10mm upward bend from the forward mount to the top
4/00/2045		DADNO54	
4/08/2015		PARN251	Once the supplied HPDM was fitted to resolve the monitor up light staying on, both pump panel touch switches no longer worked
24/08/2015		PARN251	No DC power at Merlin board magnetic plug
13/10/2015		PARN251	O/S hose reel rewind not operating and unable to use manual rewind as gears not engaging.
23/10/2015		PARN251	Replaced bulb
18/01/2016		PARN251	Foam tank refill pump not working
19/01/2016		PARN251	Hose reel repairs
19/01/2016		PARN251	Bearing play
27/01/2016		PARN251	Foam system not working as expected on hose reels
18/03/2016		PARN251	4x delivery outlets couplings loose
18/03/2016		PARN251	Fuse box at battery box [battery charger fuse fizzed] electrical fungus
26/05/2016		PARN251	Foam refill pump not working due to switch input of HDPDM failed
31/05/2016		PARN251	Non-skid paint on roof of locker body peeling off
13/06/2016	5 JCT115	PARN251	Reprogramme switch panel
		X	
		▼	

Date Unit Num	ber Appliance	Fault detail Foam tank level, stand pipe bracket, TIC charger, door Spring bolt Mast light warning light staying on (RHS) Merlin board repair Replace bulb and repair valve leak Door issue Door cable Door catch Rocker cover gasket Door issue Door issue <t< th=""></t<>
20/06/2016 JCT115	PARN251	Foam tank level, stand pipe bracket, TIC charger, door
20/06/2016 JCT115	PARN251	Spring bolt
20/06/2016 JCT115	PARN251	Mast light warning light staying on (RHS)
27/06/2016 JCT115	PARN251	Merlin board repair
19/08/2016 JCT115	PARN251	Replace bulb and repair valve leak
30/08/2016 JCT115	PARN251	Door issue
30/08/2016 JCT115	PARN251	Door handle
6/09/2016 JCT115	PARN251	Door cable
16/09/2016 JCT115	PARN251	Door catch
23/09/2016 JCT115	PARN251	Rocker cover gasket
27/09/2016 JCT115	PARN251	Door issue
10/10/2016 JCT115	PARN251	Door issue
11/10/2016 JCT115	PARN251	Door latches
18/11/2016 JCT115	PARN251	Door hinge
7/12/2016 JCT115	PARN251	Monitor valve not closing off fully, leaking out bleed hole.
24/07/2017 JCT115	PARN251	Clean sight glass, free up valves
18/08/2017 JCT115	PARN251	Replace battery
18/08/2017 JCT115	PARN251	Repair drawer, TPM and relay
30/07/2015 JCT65	HAMI411	Nearside hose reel branch holder broken
4/08/2015 JCT65	HAMI411	Foam Pro only supplies foam to the hose reels, doesn't supply to low pressure deliveries and monitor.
18/08/2015 JCT65	HAMI411	Clamp
14/09/2015 JCT65	HAMI411	Repair foam system
17/09/2015 JCT65	HAMI411	When pumping, pressed the IDLE button on the electronic throttle and all the pump electronic system went 'dead'.
18/09/2015 JCT65	HAMI411	Mast up light remains on in the cab even when both masts are completely and correctly housed
29/09/2015 JCT65	HAMI411	The portable pump charger unit in the Type 3 MAN is not charging.
12/10/2015 JCT65	HAMI411	Charging fault
14/10/2015 JCT65	HAMI411	Mast light fault
19/10/2015 JCT65	HAMI411	The pump throttle stops working on the appliance.
27/11/2015 JCT65	HAMI411	The MAN at Hamilton has developed the same defect regarding the pump throttle.
4/12/2015 JCT65	HAMI411	A piece of plastic fell out of one of the runners on a locker door on 411. The locker also jammed and we were unable to close.
18/12/2015 JCT65	HAMI411	The pump throttle issue is still happening
13/01/2016 JCT65	HAMI411	The pump throttle issue is still happening.
19/01/2016 JCT65	HAMI411	Foam pump fault
	X -	
	*	

Date	Unit Number	Appliance	Fault detail
19/01/2016		HAMI411	Calibrate foam and kunkle valve
19/01/2016		HAMI411	HP hose fault
,,			Scene light mast switches are defective. The light won't switch on/off and the switch to move the light unit up and down doesn't
27/01/2016	JCT65	HAMI411	work.
, - ,			RHS lock barrel in the door handle won't unlock the door. The key continually turns without operating the lock. The door can only
18/02/2016	JCT65	HAMI411	be opened from the inside.
18/02/2016		HAMI411	The Nearside light control switches are not working.
19/02/2016		HAMI411	Non-slip material cracking and lifting off the body roof area of the truck.
16/03/2016		HAMI411	The non slip surface, on the top of the body, is cracking and peeling off in several places.
17/03/2016		HAMI411	Switch panel
17/03/2016	JCT65	HAMI411	Misc minor faults
18/03/2016	JCT65	HAMI411	The orange light comes up on the dash and EPS displays in the dash screen.
18/04/2016	JCT65	HAMI411	Repair dash trim
2/05/2016	JCT65	HAMI411	Grab handles in the cab are coming loose.
9/05/2016	JCT65	HAMI411	Fit earth strap
19/05/2016	JCT65	HAMI411	Replacement, upgraded air horn is defective.
24/05/2016	JCT65	HAMI411	Mast Up light stays illuminated on the dash.
7/06/2016	JCT65	HAMI411	Check horn wires
15/06/2016	JCT65	HAMI411	Radiator leak
15/06/2016	JCT65	HAMI411	Repair mast light wiring
30/06/2016	JCT65	HAMI411	Spilt diesel
11/07/2016	JCT65	HAMI411	Clean sight tube
4/08/2016	JCT65	HAMI411	Puncture repair
14/09/2016	JCT65	HAMI411	Monitor control valve leaking under pressure.
14/09/2016	JCT65	HAMI411	Defective swivel joint on nearside hose reel drum
13/10/2016	JCT65	HAMI411	Foam refill button not operating
17/10/2016	JCT65	HAMI411	Malfunction of Engine Control Unit displays on the dash and the transmission take a long time to change.
18/10/2016	JCT65	HAMI411	Clean sight tube, minor leak
18/11/2016	JCT65	HAMI411	Faulty lamba probe
25/11/2016		HAMI411	Air horn intermittently works loud then goes quiet while operating when responding to incidents.
19/12/2016		HAMI411	Foam pump fault
31/12/2016		HAMI411	Replace shelf slider
5/01/2017		HAMI411	O/S rear cab door has dropped on its hinges and is difficult to open.
6/01/2017		HAMI411	When the foot brake is bumped or applied the pump disengages.
11/01/2017	JCT65	HAMI411	Tighten exhaust clamp
		X	

Date	Unit Number	Appliance	Fault detail
17/01/2017		HAMI411	Fix shelf
20/01/2017		HAMI411	Drawer slides
26/01/2017		HAMI411	Fit new drawer hinge
24/02/2017		HAMI411	Cab locker latch broken
27/02/2017		HAMI411	Broken branch holder
13/03/2017		HAMI411	Driver's side grab handles are coming loose. Officer's side grab handles also appear to be working loose.
13/03/2017		HAMI411	TPM slow to respond to pressure changes and does not open the second stage to relieve to waste.
13/03/2017	JCT65	HAMI411	The top mounted coffin is working loose on the mountings
13/03/2017	JCT65	HAMI411	Pump panel alarm intermittently activating
28/03/2017	JCT65	HAMI411	Trans oil sample shows elevated traces of aluminium
10/04/2017	JCT65	HAMI411	Irans oil sample shows elevated traces of aluminium Misc minor faults Flat batteries Locker light not working Relief valve TPM fault TPM fault Replace light bulb
2/05/2017	JCT65	HAMI411	Flat batteries
11/05/2017	JCT65	HAMI411	Locker light not working
8/06/2017	JCT65	HAMI411	Relief valve
15/06/2017	JCT65	HAMI411	TPM fault
20/07/2017	JCT65	HAMI411	TPM fault
2/08/2017	JCT65	HAMI411	Replace light bulb
18/08/2017	JCT65	HAMI411	Repair drawer and clean TPM
29/08/2017	JCT65	HAMI411	Clean TPM
13/10/2015	JEL373	PAPA347	240v to 24v charger not working intermittently
3/12/2015	JEL373	PAPA347	Modify kick panel
21/12/2015	JEL373	PAPA347	Butterfly inlet valve link rod not allowing valve to fully close
21/12/2015	JEL373	PAPA347	Drivers door internal release handle cable broken
23/12/2015	JEL373	PAPA347	Reported throttle issue
13/01/2016	JEL373	PAPA347	Butterfly inlet valve link rod not allowing valve to fully close
13/01/2016	JEL373	PAPA347	Drivers door internal release handle cable broken
14/01/2016	JEL373	PAPA347	Non slip paint on roof delaminating and falling off. Conspicuity tape lifting across front of truck
19/01/2016	JEL373	PAPA347	Switch panel
12/02/2016	JEL373	PAPA347	Foam Pro flow meter paddle wheel leaking
19/02/2016	JEL373	PAPA347	Warning on dash
19/02/2016	JEL373	PAPA347	Clean valve
18/03/2016	JEL373	PAPA347	Relief valve drain hose split as it is crushed between fuel tank & amp; pump frame bracket.
4/04/2016	JEL373	PAPA347	Rivets failing on top side panels.
4/04/2016	JEL373	PAPA347	Side emergency flasher wiring damaged by rear wheel as not secured sufficiently
18/04/2016	JEL373	PAPA347	Puncture repair

Date	Unit Number	Angliance	Fault detail Pump panel reset Both pump panel soft touch controls have stopped working. Papatoetoe T3M Rego JEL373 has had a mast unhoused light come on. Replace bulb Replace bulbs Rear locker to I/h rear HPDM has been shorting or over loading. Water leaking into nearside C locker front wall Off side Inlet valve not sealing - losing prime Replace check valve Replace bulb, washers, check valve Repair Merlin board Locker slider Oil leak Partice sume specified
4/05/201		Appliance PAPA347	Pump panel reset
24/05/201		PAPA347	Both pump panel soft touch controls have stopped working.
31/05/201		PAPA347	Papatoetoe T3M Rego JEL373 has had a mast unhoused light come on.
26/07/201		PAPA347	Replace bulb
10/08/201		PAPA347	Replace bulbs
11/08/201		PAPA347	Rear locker to I/h rear HPDM has been shorting or over loading.
17/08/201		PAPA347	Water leaking into nearside C locker front wall
17/08/201		PAPA347	Off side Inlet valve not sealing - losing prime
31/08/201		PAPA347	Replace check valve
19/09/201		PAPA347	Replace bulb, washers, check valve
19/09/201		PAPA347	Repair Merlin board
23/09/201		PAPA347	Locker slider
20/10/201		PAPA347	Oil leak
31/10/201		PAPA347	Rocker cover gasket
4/11/201		PAPA347	Switch panel issue
			Hose reel rewind jammed on. Stopped when nozzle jammed in rollers. Ongoing intermittent issues with the pump panel switch
16/11/201	.6 JEL373	PAPA347	panels. They keep losing their program
7/12/201	.6 JEL373	PAPA347	Light fault
7/12/201	.6 JEL373	PAPA347	Light fault
17/02/201	7 JEL373	PAPA347	Check foam operation
3/03/201	7 JEL373	PAPA347	Replace battery
12/06/201	7 JEL373	PAPA347	Flat battery
18/08/201	7 JEL373	PAPA347	Repair drawer, TPM and replace batteries
26/01/201	.6 JGY376	SOCK257	Right rear door not closing properly,
11/02/201	.6 JGY376	SOCK257	Pump hours meter not working. Water leak from pump cooler hose
29/02/201	.6 JGY376	SOCK257	BA board not charging
1/03/201	.6 JGY376	SOCK257	Head rests on BA seats coming loose
24/03/201	.6 JGY376	SOCK257	Broken branch holder
15/08/201		SOCK257	Nearside rear window won't wind up or down, window winder mechanism broken(?) inside the door.
19/09/201		SOCK257	Pump wont hold vacuum, gasket around the inlet valve has split
21/09/201		SOCK257	Replace reflector
	.6 JGY376	SOCK257	#4 delivery gauge not working
19/10/201		SOCK257	BA board power supply
	.6 JGY376	SOCK257	Outer skin on rear cab doors has split off the door frame between the hinge mounts
12/01/201	7 JGY376	SOCK257	Gauge not reading

Data	U	A	
Date		Appliance	Fault detail
12/01/2017	JG13/0	SOCK257	Misc repairs
20/10/2015		CUD1217	Offside front corner panel has been damaged, then plastic welded and painted. The weld has not held and the panel has torn off
29/10/2015		CHRI217	when traveling at open road speed.
21/12/2015		CHRI217	Drain hose from the TPM valve tangled in the delivery lever mechanism and cut in half
13/01/2016		CHRI217	Drain hose from the TPM valve tangled in the delivery lever mechanism and cut in half
26/01/2016		CHRI217	Ladder lock shedding the rubber strips where it clamps over the ladder rounds
28/01/2016	JHU481	CHRI217	Diesel fuel leaking around the fuel cap. Fuel blowing back when filling the tank
11/02/2010		CUD1217	Latches on sliding drawer in the nearside B locker have broken off, drawer slides out by itself and interferes with the roller door
11/02/2016		CHRI217	when shut
18/02/2016		CHRI217	Both side inlet valves seized and unable to be opened
25/02/2016		CHRI217	Head rests on BA seats coming loose Roller door guide broken through the weld
29/02/2016		CHRI217	
11/03/2016		CHRI217	Puncture repair
18/04/2016		CHRI217	Repair guard flare
18/04/2016		CHRI217	Rivet sheared off at the centre top body panel
27/05/2016		CHRI217	Top panel above locker doors pop rivets broken out. Top coffin mounts loose
21/06/2016		CHRI217	Rear doors have dropped and no longer shut properly, rust showing on spot welds around door hinges
2/12/2016		CHRI217	Broken mounts
20/01/2017		CHRI217	Replace batteries
18/08/2017	JHU481	CHRI217	Repair drawer and clean TPM
			Off side hose reel rewind button is jammed in the on position and now the circuit breaker has tripped. The light switches on the off
9/11/2015		NEWT221	side pump panel do not appear to be working. The off side middle locker door is catching on the upper locker roof panel.
14/12/2015		NEWT221	Flat batteries
6/01/2016		NEWT221	Light Mast Up warning light staying on even with mast down.
13/01/2016		NEWT221 NEWT221	Light Mast Up warning light staying on even with mast down
22/01/2016		NEWT221	Nearside rear internal door handle dislodged and not able to open door from inside.
4/02/2016		NEWT221	Replace indicator
23/02/2016		NEWT221	Both inlet valves not closing fully, noticed bolt on linkage has sheared off. Monitor valve not closing fully
26/02/2016		NEWT221	Repair door handle
26/02/2016		NEWT221	Door fault
26/02/2016		NEWT221	Main Pump Hour meter not working
23/03/2016		NEWT221 NEWT221	Door adjustment
11/05/2016		NEWT221 NEWT221	Repair locker door
		NEWT221 NEWT221	
13/06/2016	JJE400	INE VV I ZZI	Faulty guage

			Fault detail No 1 Delivery gauge line blocked Door adjustment Replace mirror No 2 Delivery gauge line blocked and not able to be cleared. TPM not resetting when being fed from hydrant supply Adjust door TPM repair Nearside A locker door guide popping rivets Door adjustment Damaged hose ramp pins Not holding prime, water leak Door adjustment Secure step Repair door Door adjustment Adjust door and delivery linkage Software update Inlet valve butterfly and mechanism not closing valve properly Broken bolt on butterfly valve Free up valve
Date	Unit Number	Appliance	Fault detail
13/06/2016	JJE408	NEWT221	No 1 Delivery gauge line blocked
13/07/2016	JJE408	NEWT221	Door adjustment
29/08/2016	JJE408	NEWT221	Replace mirror
29/09/2016	JJE408	NEWT221	No 2 Delivery gauge line blocked and not able to be cleared.
14/10/2016	JJE408	NEWT221	TPM not resetting when being fed from hydrant supply
15/12/2016	JJE408	NEWT221	Adjust door
31/12/2016	JJE408	NEWT221	TPM repair
13/02/2017	′ JJE408	NEWT221	Nearside A locker door guide popping rivets
22/02/2017	′ JJE408	NEWT221	Door adjustment
7/04/2017	′ JJE408	NEWT221	Damaged hose ramp pins
22/05/2017	′ JJE408	NEWT221	Not holding prime, water leak
21/06/2017	' JJE408	NEWT221	Door adjustment
21/06/2017	' JJE408	NEWT221	Secure step
3/08/2017	' JJE408	NEWT221	Repair door
3/08/2017	' JJE408	NEWT221	Door adjustment
17/08/2017	' JJE408	NEWT221	Adjust door and delivery linkage
19/01/2016	JJT25	REMU211	Software update
26/01/2016	JJT25	REMU211	Inlet valve butterfly and mechanism not closing valve properly Broken bolt on butterfly valve Free up valve
26/01/2016	JJT25	REMU211	Rubber buffer on clamp that drops over ladder rung has become detached from the rivet
27/01/2016	JJT25	REMU211	Little giant ladder not extending as required. Retainer not operating correctly
11/02/2016	JJT25	REMU211	Number's 1, 2, 3 and 4 delivery instantaneous couplings have come lose and leaking water under pressure.
18/03/2016	JJT25	REMU211	Left hand outside beacon fell off.
7/04/2016	JJT25	REMU211	Blown gasket at discharge head pipe work leading to N/S deliveries and monitor
30/06/2016	JJT25	REMU211	Hubometer failed
10/08/2016	JJT25	REMU211	Replace washers
13/12/2016	JJT25	REMU211	Mast up light on when mast is down
14/12/2016	JJT25	REMU211	Repair Merlin plug, clean valve
18/08/2017	JJT25	REMU211	Repair valve
3/12/2015	JKT21	BROO251	Off side rear door doesn't unlock with the central locking
3/12/2015	JKT21	BROO251	Noticed water coming into Off side A locker.
15/12/2015	JKT21	BROO251	Locker Open warning light staying on even with all the locker doors closed.
21/01/2016	JKT21	BROO251	Locker Open warning light always on even with all locker doors closed
21/01/2016	JKT21	BROO251	TPM not operating correctly.
16/02/2016	JKT21	BROO251	Water leak
		-	

DateUnit NumberApplianceFault detail23/02/2016INT21BR00251Internal cab door handle come apart and not able to open door25/02/2016INT21BR00251Internal cab door handle come apart and not able to open door26/02/2016INT21BR00251Fuel contamination TPM Dump hose has split, also end of hose is not clamped causing the hose to turn around and dump the water upwards into he31/12/2016INT21BR00251Dash light fault22/02/2017INT21BR00251Iab tabteries31/02/2016INT21BR00251Iab tabteries31/02/2016ILS330MANU301Inter vale linkage broken30/06/2017INT21BR00251Ight fault30/06/2017ILS330MANU301Inter vale linkage broken30/06/2016ILS330MANU301Inter vale linkage broken20/05/2016ILS330MANU301Inter vale linkage broken20/05/2016ILS330MANU301Compound gauge not working.7/07/2016ILS330MANU301Epain light20/05/2016ILS330MANU301Repair inter vale20/05/2016ILS330MANU301Epain light vale20/05/2016ILS330MANU301Epain light vale20/05/2016ILS330MANU301Epain light vale21/10/2016ILS330MANU301Epain light vale21/10/2016ILS330MANU301Epain light vale21/10/2016ILS330MANU301Epain light vale21/10/2016ILS330<				
26/02/2016 IKT21 BR00251 Flat batteries 13/06/2016 IKT21 BR00251 Water leak and vacuum issue 30/06/2016 IKT21 BR00251 Fuel contamination TPM Dump hose has split, also end of hose is not clamped causing the hose to turn around and dump the water upwards into he 31/12/2016 IKT21 BR00251 Dash light fault 22/02/2017 IKT21 BR00251 Dash light fault 21/06/2017 IKT21 BR00251 Vater leak and broken radio holder 30/06/2017 IKT21 BR00251 Light fault 31/03/2016 ILS330 MANU301 Flat batteries 31/03/2016 ILS330 MANU301 Inlet valve linkage broken 28/04/2016 ILS330 MANU301 Inlet valve linkage broken 20/05/2016 ILS330 MANU301 Pump panel reprogramme 20/05/2016 ILS330 MANU301 Pum panel reprogramme 20/05/2016 ILS330 MANU301 Repair inlet valve 21/12/2016 ILS330 MANU301 Repair inlet valve 21/12/2016 ILS330 MANU301 Repair inlet valve <th></th> <th></th> <th>• •</th> <th></th>			• •	
13/06/2016KT21BRO251Water leak and vacuum issue30/06/2016KT21BRO251Fuel contamination TPM Dump hose has split, also end of hose is not clamped causing the hose to turn around and dump the water upwards into he4/10/2016KT21BRO251pump area.31/12/2016BRO251Dash light fault22/02/2017KT21BRO251Flat batteries19/06/2017KT21BRO251Light fault30/06/2017KT21BRO251Light fault19/06/2017KT21BRO251Light fault19/01/2016LIS330MANU301Flat battery31/03/2016JIS330MANU301Flat battery20/05/2016LIS330MANU301Cab level20/05/2016JIS330MANU301Pump panel reprogramme20/05/2016JIS330MANU301Compound gauge not working.7/07/2016JIS330MANU301Compound gauge not working.7/07/2016JIS330MANU301Repair inlet valve31/10/2016JIS330MANU301Repair inlet valve31/10/2016JIS330MANU301Repair inlet valve31/10/2016JIS330MANU301Repair inlet valve31/11/2016JIS330MANU301Repair inlet valve31/11/2016JIS330MANU301Repair inlet valve31/11/2016JIS330MANU301Repair inlet valve31/11/2016JIS330MANU301Repair inlet valve31/11/2016JIS330MANU301Repair inlet valve </td <td></td> <td></td> <td></td> <td></td>				
30/06/2016 IKT21BRO0251Fue contamination TPM Dump hose has split, also end of hose is not clamped causing the hose to turn around and dump the water upwards into he31/12/2016 IKT21BRO0251Dash light fault22/02/2017 IKT21BRO0251Dash light fault22/02/2017 IKT21BRO0251Vater leak and broken radio holder30/06/2017 IKT21BRO0251Light fault30/06/2017 IKT21BRO0251Light fault30/06/2016 ILS330MANU301Inlet valve linkage broken28/04/2016 ILS330MANU301Pump panel reprogramme20/05/2016 ILS330MANU301Pomp und gauge not working.7/07/2016 ILS330MANU301Compound gauge not working.31/10/2016 ILS330MANU301Cole and plug31/10/2016 ILS330MANU301Repair inlet valve31/10/2016 ILS330MANU301Fault y check valve31/10/2016 ILS330MANU301Repair inlet valve31/10/2016 ILS330MANU301Repair inlet valve31/10/2016 ILS330MANU301Repair inlet valve31/10/2016 ILS330MANU301Repair inlet valve				
4/10/2016 IXT21 BR00251 pump area. 3/1/2/2016 IXT21 BR00251 Dash light fault 2/20/2/2017 IXT21 BR00251 Flat batteries 13/06/2017 IXT21 BR00251 Light fault 2/20/2/2017 IXT21 BR00251 Light fault 3/06/2017 IXT21 BR00251 Light fault 3/06/2017 IXT21 BR00251 Light fault 3/06/2017 IXT21 BR00251 Light fault 3/06/2016 Lis330 MANU301 Flat battery 3/03/2016 Lis330 MANU301 Inter valve linkage broken 2/06/2016 Lis330 MANU301 Compound gauge not working. 3/07/2016 Lis330 MANU301 Compound gauge not working. 3/07/2016 Lis330 MANU301 Boari inbet valve 3/07/2016 Lis330 MANU301 Boari anited valve 3/07/2016 Lis330 MANU301 Repair inlet valve 3/10/2016 Lis330 MANU301 Repair inlet v				
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights	30/06/201	6 JKT21	BROO251	Fuel contamination
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights				TPM Dump hose has split, also end of hose is not clamped causing the hose to turn around and dump the water upwards into he
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights				pump area.
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights			BROO251	Dash light fault
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights			BROO251	Flat batteries
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights			BROO251	Water leak and broken radio holder
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights			BROO251	Light fault
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights			MANU301	Flat battery
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights			MANU301	Inlet valve linkage broken
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights	28/04/201	6 JLS330	MANU301	Cab level
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights	16/05/201	6 JLS330	MANU301	Pump panel reprogramme
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights	20/05/201	6 JLS330	MANU301	Foam light
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights	20/05/201	6 JLS330	MANU301	Compound gauge not working.
17/08/2016 JLS330MANU301Door latch23/09/2016 JLS330MANU301Repair inlet valve31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Replace locker slider23/12/2016 JLS330MANU301Replace locker slider24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Repair Reverse lights	7/07/201	6 JLS330	MANU301	Merlin board plug
31/10/2016 JLS330MANU301Clean foam system4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Repair air leak, adjust door23/12/2016 JLS330MANU301Foam tank refill pump not working.14/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair air leak, adjust door15/01/2017 JLS330MANU301Repair et heap liance is plugged into a station it trips the station circuit breaker15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Reverse lights not operating7/04/2016 JLS360ADDI221Repair Reverse Lights	17/08/201	6 JLS330	MANU301	
4/11/2016 JLS330MANU301Faulty check valve11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Repair air leak, adjust door23/12/2016 JLS330MANU301Foam tank refill pump not working.14/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	23/09/201	6 JLS330	MANU301	Repair inlet valve
11/11/2016 JLS330MANU301Aerial damage21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Repair air leak, adjust door23/12/2016 JLS330MANU301Foam tank refill pump not working.14/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Bulbs18/08/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	31/10/201	6 JLS330	MANU301	Clean foam system
21/11/2016 JLS330MANU301Butterfly valve for roof monitor to tight for actuator to move13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Repair air leak, adjust door23/12/2016 JLS330MANU301Foam tank refill pump not working.14/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Bulbs18/08/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	4/11/201	6 JLS330	MANU301	Faulty check valve
13/12/2016 JLS330MANU301Replace locker slider20/12/2016 JLS330MANU301Repair air leak, adjust door23/12/2016 JLS330MANU301Foam tank refill pump not working.14/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Bulbs18/08/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	11/11/201	6 JLS330	MANU301	Aerial damage
20/12/2016 JLS330MANU301Repair air leak, adjust door23/12/2016 JLS330MANU301Foam tank refill pump not working.14/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Bulbs18/08/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	21/11/201	6 JLS330	MANU301	Butterfly valve for roof monitor to tight for actuator to move
23/12/2016 JLS330MANU301Foam tank refil pump not working.14/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Bulbs18/08/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Reverse lights not operating7/04/2016 JLS360ADDI221Repair Reverse Lights	13/12/201	6 JLS330	MANU301	Replace locker slider
14/07/2017 JLS330MANU301Replace check valve and rocker cover gasket24/07/2017 JLS330MANU301Bulbs18/08/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Reverse lights not operating7/04/2016 JLS360ADDI221Repair Reverse Lights	20/12/201	6 JLS330	MANU301	Repair air leak, adjust door
24/07/2017 JLS330MANU301Bulbs18/08/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	23/12/201	6 JLS330	MANU301	Foam tank refill pump not working.
18/08/2017 JLS330MANU301Repair TPM15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	14/07/201	7 JLS330	MANU301	Replace check valve and rocker cover gasket
15/01/2016 JLS360ADDI221Every time the appliance is plugged into a station it trips the station circuit breaker25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	24/07/201	7 JLS330	MANU301	Bulbs
25/02/2016 JLS360ADDI221Head rests on BA seats coming loose9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	18/08/201	7 JLS330	MANU301	Repair TPM
9/03/2016 JLS360ADDI221Reverse lights not operating17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	15/01/201	6 JLS360	ADDI221	Every time the appliance is plugged into a station it trips the station circuit breaker
17/03/2016 JLS360ADDI221Rear cab doors have dropped and are hard to close7/04/2016 JLS360ADDI221Repair Reverse Lights	25/02/201	6 JLS360	ADDI221	Head rests on BA seats coming loose
7/04/2016 JLS360 ADDI221 Repair Reverse Lights	9/03/201	6 JLS360	ADDI221	Reverse lights not operating
	17/03/201	6 JLS360	ADDI221	Rear cab doors have dropped and are hard to close
7/04/2016 JLS360 ADDI221 Faulty Hazard Light	7/04/201	6 JLS360	ADDI221	Repair Reverse Lights
	7/04/201	6 JLS360	ADDI221	Faulty Hazard Light

Date	Unit Number	Appliance	Fault detail
7/04/2016	5 JLS360	ADDI221	Flat battery
			Headlights are on even though the switch is off. High beams don't work. Fault showing on the dash when the beacons are turned
17/05/2016	5 JLS360	ADDI221	on
			On board computer malfunction appears on dash when the beacons are activated. Hazard lights make the park lights flash. Low
27/05/2016		ADDI221	beams come on when the hazards are activated. Park lights come on with the ignition. Low beams stay on with the headlights off
31/05/2016	5 JLS360	ADDI221	Foam change over lights not working. Pump drain valve knob fallen off
31/05/2016	5 JLS360	ADDI221	Engine dipstick will not fit into the tube properly, giving a false oil level reading, tube and stick don't appear to be compatible
			Cracks showing in the painted joints between the steel part of the rear doors and the fibre glass extensions top and bottom, both
31/05/2016		ADDI221	sides
15/06/2016		ADDI221	Repair guard flare
15/07/2016		ADDI221	Warranty
9/09/2016		ADDI221	Rear light fault
6/10/2016		ADDI221	Replace socket
1/12/2016		ADDI221	Engine starts with 240v plugged in, faulty relay
6/12/2016		ADDI221	Outer skin on rear cab doors has split off the door frame between the hinge mounts
21/02/2017		ADDI221	Fuel leak
23/02/2017		ADDI221	Minor repairs
17/03/2017		ADDI221	Puncture repair
8/05/2017		ADDI221	Replace Driving Lamp
15/05/2017		ADDI221	Replace bulb
25/07/2017		ADDI221	Repair relay and TPM
26/01/2016		OTAH311	Inlet butterfly valve leaking and sticking.
27/04/2016		OTAH311	Every time the 240v power to the truck is switched off the RCD on station (all) trips
4/05/2016		OTAH311	LR rear door handle broken leaving door to be inoperable from inside and outside (locked)
6/05/2016		OTAH311	Hose reel and panel not working
30/05/2016		OTAH311	Broken branch latch
28/06/2016		OTAH311	Misc minor issues
14/07/2016		OTAH311	Air filter light coming on.
1/08/2016		OTAH311	Pump throttle failed to operate.
16/09/2016		OTAH311	Faulty locker door switch
10/10/2016		OTAH311	Hazard siren speaker failed
14/10/2016		OTAH311	Siren fault
18/10/2016	JIVIQ958	OTAH311	Locker door switch failed

Date Un	it Number	Appliance	Fault detail Nearside inlet valve not sealing Vacuum fault Foam pump not working Locker open warning light on, even when all lockers are fully closed Adjust door Clean TPM, replace batteries
11/11/2016 JM			Nearside inlet valve not sealing
30/11/2016 JM			Vacuum fault
7/12/2016 JM			Foam pump not working
13/12/2016 JM			Locker open warning light on, even when all lockers are fully closed
14/12/2016 JM			Adjust door
25/07/2017 JM			Clean TPM, replace batteries
18/04/2016 JNN			Siren doesn't go, speaker faulty
-,-,			Pump was engaged but pump panel throttle would not work, the pump operator used the foot throttle control in the cab to
25/05/2016 JNN	M771		control the pump.
27/05/2016 JNN		HARE261	Rivets broken in top panel above locker doors
4/07/2016 JNN			Tank to pump valve not fully closing
11/07/2016 JNN	M771		Pump panel buttons faulted
15/07/2016 JNN		HARE261	Check Headlights, Axle Kingpin
13/01/2017 JNN	M771		Minor repairs
17/01/2017 JNN	M771		Air conditioning not cold enough, air con compressor faulty
7/02/2017 JNM	M771	HARE261	The safety latches on the drawer slides are not automatically engaging.
22/02/2017 JNN	M771	HARE261	Misc repairs
17/03/2017 JNN	M771	HARE261	Puncture repair
7/04/2017 JNN	M771	HARE261	Air leak
2/06/2017 JNN	M771	HARE261	Puncture repair 🔿
9/08/2017 JNN	M771	HARE261	Puncture repair Puncture repair
			Three of the switches on the N/S pump panel controlling mast light tilt, mast light ON/OFF and scene light ON/OFF are not
14/04/2016 JQI	L46	CHAR427	functioning for the N/S lights.
14/04/2016 JQI	L46	CHAR427	Water leaking into locker above frame in rear lockers.
14/04/2016 JQI	L46	CHAR427	Beacons and side body flashers not operating
14/04/2016 JQI	L46	CHAR427	Water leaking in to both front cab doors and the RHS rear cab door.
14/04/2016 JQI	L46	CHAR427	Tank to pump valve has jammed in the closed position.
25/05/2016 JQI	L46	CHAR427	Rear beacons and switches not working
30/06/2016 JQI	L46	CHAR427	Rear cab doors not sealing at the bottom. Appears to catching on bottom of door frame.
7/07/2016 JQI	L46	CHAR427	Repair locker shelf
11/07/2016 JQI	L46	CHAR427	RHS rear door came open on the way to a call. Door has been checked by crew and seems hard to shut to the second latch.
18/08/2016 JQI	L46	CHAR427	Tripped breaker
20/09/2016 JQI	L46	CHAR427	Map light fault
20/09/2016 JQI	L46	CHAR427	Adjust hose reel
	X		
		-	

Date Unit N	umber Appliance	Fault detail
15/12/2016 JQL46	CHAR427	Bent latch
19/12/2016 JQL46	CHAR427	Replace interior light
6/01/2017 JQL46	CHAR427	When the foot brake is bumped or applied the pump disengages.
26/04/2017 JQL46	CHAR427	Relocate exhaust mount bracket
2/05/2017 JQL46	CHAR427	Damaged latch bar
24/06/2016 JQL50	PALM211	Rear Beacon doesn't work.
5/07/2016 JQL50	PALM211	Siren Speaker Failure
25/07/2016 JQL50	PALM211	Roller Shutters hard to open need to use a lot of force.
23/08/2016 JQL50	PALM211	Siren fault
6/09/2016 JQL50	PALM211	Reports of wiring for NZFS comms too short making it harder to remove the radio hardware in the event of a fault.
28/09/2016 JQL50	PALM211	Battery clamp was fitted upside down damaging battery post
30/09/2016 JQL50	PALM211	Replace o ring
29/11/2016 JQL50	PALM211	Puncture repair
15/12/2016 JQL50	PALM211	Leaking inlet seal
15/12/2016 JQL50	PALM211	Weather strip loose
13/01/2017 JQL50	PALM211	Broken master switch
27/01/2017 JQL50	PALM211	Broken branch holder and misc minor faults
8/03/2017 JQL50	PALM211	Primer repair
15/03/2017 JQL50	PALM211	Vacuum and hose reel leaks
5/05/2017 JQL50	PALM211	Broken battery clamp
30/05/2017 JQL50	PALM211	Repair seat belt
18/08/2017 JQL50	PALM211	Clean TPM lines
25/05/2016 JRK496	5 NHQN32016	Battery charger not charging batteries.
23/09/2016 JRK496	5 NHQN32016	
11/10/2016 JRK496	5 NHQN32016	Rear door latches
15/03/2017 JRK496	5 NHQN32016	Foam pump and priming issues, water leak
21/08/2017 JRK496	5 NHQN32016	Vacuum leak
14/07/2016 JRK508	3 NHQN32116	Flat batteries
27/09/2016 JRK508	3 NHQN32116	Adjust locker door
29/03/2017 JRK508	3 NHQN32116	LH pump panel switch panel not working
31/03/2017 JRK508	3 NHQN32116	Foam tank refill pump not working
31/03/2017 JRK508	3 NHQN32116	RH mast light motor housing rusting
20/04/2017 JRK508	3 NHQN32116	Priming fault, damaged fuel cap
18/08/2017 JRK508	3 NHQN32116	Replace sightglass tube
17/01/2017 JTJ88	NHQN32416	Door repairs

Date	Unit Number	Appliance	Fault detail
25/01/2017		NHQN32416	Airline from the APS to the air horn dropped down onto the exhaust and melted through
31/01/2017		NHQN32416	Repair rear doors
17/03/2017	JTJ88	NHQN32416	Charger fault
30/06/2016	JUK864	NHQN32516	Some of the bolts (on the O/S) that secure the front panel across both body sections are loose (finger tight).
			There appears to be a fault with the N/S light switch panel. The hose reel rewind does not work and there is a row of red lights
1/07/2016	JUK864	NHQN32516	flashing
22/09/2016	JUK864	NHQN32516	Locker Open light always on even with all locker doors closed
23/09/2016	JUK864	NHQN32516	A sucking of air when engine under load (accelerating out of corners) and whistling sound can be heard (not the usual Turbo noise)
22/02/2017	JUK864	NHQN32516	Flat batteries
6/04/2017	JUK864	NHQN32516	Central locking fault
21/06/2017	JUK864	NHQN32516	Flat batteries
29/06/2017	JUK909	NHQN32616	Inlet valve repair
30/06/2016	JWF973	NHQN32716	The officer's door, external mirror top mount was loose.
27/10/2016	JWF973	NHQN32716	Locker door warning light is on but all doors are closed
25/07/2017	JWF973	NHQN32716	Stiff valves, bulb
17/01/2017	JZH634	NHQN32816	Kysor alarm sounding.
31/01/2017	JZH634	NHQN32816	Coolant warning issue
8/03/2017	JZH634	NHQN32816	Reinstall 240V socket
8/03/2017	JZH634	NHQN32816	Primer fault
8/03/2017	JZH634	NHQN32816	TPM fault
12/04/2017	JZH634	NHQN32816	Coolant warning issue
29/06/2017	JZH634	NHQN32816	Coolant warning issue
18/08/2017	KBL126	NHQN33016	Replace battery
18/08/2017	KET171	THOR231	Replace battery
6/01/2016		#N/A	TPM PG30 relief valve hose has come off and water is going everywhere when relief valve operates.
13/01/2016		#N/A	TPM PG30 relief valve hose has come off and water is going everywhere when relief valve operates

Released